1	Before driving	1-5.	Opening the fuel tank cap	
1-1.	Key information2	1-6.	Anti-theft system	50
	Keys 2		Engine immobilizer system.	
1-2.	Opening, closing and locking the doors and trunk4		Theft prevention labels (U.S.A.)	54
	Smart access system with push-button start	1-7.	Safety information	55
	Wireless remote control 12		Correct driving posture	55
	Doors		SRS airbags	57
	Trunk 19		Child restraint systems	68
			Installing child restraints	71
1-3.	Adjustable components22			
	Front seats 22	2	When driving	
	Driving position memory 24	2	vv nen ariving	
	Seat position memory			
	Head restraints29	2-1.	Driving procedures	82
	Seat belts 30		Driving the vehicle	82
	Steering wheel		Starting the engine	89
	(manually adjustable type) 36		Automatic Transmission	92
	Steering wheel		Manual Transmission	96
	(power-adjustable type) 37		Turn signal lever	98
	Anti-glare inside rear view mirror		Parking brake	99
	Outside rear view mirrors 39	2-2.	Instrument cluster	100
1_4	Opening and closing the		Gauges and meters	100
ıı.	windows and moon roof		Indicators and warning	
	Power windows		lights	106
	Moon roof		Multi-information display	109

2-3.	Operating the lights and windshield wipers113	3	nterior features
	Headlight switch	3-1.	Using the air conditioning system and defogger
2-4.	Using other driving systems 121		view mirror defoggers
	Cruise control	3-2.	Using the audio system 171 Audio system type 171
	Lexus parking assist-sensor 133		Using the radio174
	Driving assist systems 139		Using the CD player 181
	PCS (Pre-Collision System)144		Playing back MP3 and WMA discs 187
2-5.	Driving information147		Optimal use of the audio system 195
	Cargo and luggage 147		Using the AUX adapter198
	Vehicle load limits		Using the steering wheel audio switches
	Trailer towing	3-3.	Using the interior lights 201
	Dinghy towing (vehicles with an automatic transmission)		Interior lights list
	(vehicles with a manual transmission)158	3-4.	Using the storage features 205
			List of storage features 205 • Glove box 205 • Console boxes 206 • Overhead console 207 • Cup holders 208

	Bottle holders/door	4-2.	Maintenance	249
	pockets 209		Maintenance requirements	249
3-5	Other interior features 211		General maintenance	251
J -J.	Sun visors		Emission inspection and	
	Vanity mirror		maintenance (I/M) programs	254
	Clock		programs	ZJ 4
	Satellite switches	4-3	Do-it-yourself	
			maintenance	255
	Ashtrays		Do-it-yourself service	
	Cigarette lighter 218 Power outlet 219		precautions	255
	Seat heaters		Hood	
	Seat heaters and ventilators 222		Positioning the jack	
	Armrest 224		Engine compartment	
	Rear sunshade		Tires	
	Extended trunk		Tire inflation pressure	
	Coat hooks		Wheels	
	Floor mat		Air conditioning filter	
	Trunk features		Electronic key battery	
			Checking and replacing	
	Garage door opener		fuses	295
	Compass		Headlight aim	309
			Light bulbs	310
4	Maintenance and care			
		5	When trouble arises	
4-1.	Maintenance and care 244			
	Cleaning and protecting the vehicle exterior	5-1.	Essential information	318
	Cleaning and protecting		If your vehicle needs to	<u> </u>
	the vehicle interior 246		be towed	318
			If you think something is	205
			wrong	3ZD

	Fuel pump shut off system 326 Event data recorder 327	6-3. Initializationltems to initialize	
5-2.	Steps to take in an emergency	7 For US owners	
	If a warning light turns on or a warning buzzer sounds 329 If a warning message is displayed	Reporting safety defects for U.S.A. owners	402
	If you have a flat tire	Index	
	If the shift lever cannot be shifted from P	Alphabetical index	404
	When the electronic key battery is discharged	What to do if	413
	If the vehicle battery is discharged		
	If your vehicle overheats		
6	Vehicle specifications		
6-1.	Specifications		
	Maintenance data370		
	Fuel information 384		
	Tire information		
6-2.	Customization		
	Customizable features395		